



Wah Board Special for Xotic Wah

Because of the Wah Pedal's rubber feet, mounting it to a pedal board can be difficult and not very secure. The Wah Board Special solves this problem by providing a smooth surface for securing the Xotic Wah to your pedal board. There's no modification needed! The Wah Board Special simply mounts to the existing bottom panel and because of the recessed screws, it allows for a totally smooth surface. There's nothing protruding or getting in the way of the wah adhering solidly to the pedal board.



<Mounting Arrangement>



STEP 1 : Remove the rubber feet from the Wah and place the screws aside.

STEP 2 : Place the Wah Board Special over the bottom panel and replace the screws. After you have glued the Velcro on the back, it's ready to be set on the pedal board.

Note :

*Velcro tape is not included.

MSRP : \$20.00

Distributed by Prosound Communications Inc.

14920 Calvert Street, Van Nuys, CA 91411 USA
E-mail : info@prosoundcommunications.com